

WIRED デジタル

取扱説明書
INSTRUCTION

WIRED W36系

このたびはワイアード W36系をお買いあげいただき誠にありがとうございました。
ご使用の前にこの取扱説明書をよくお読みいただき、正しくご愛用くださいますようお願い申し上げます。
なお、この取扱説明書はお手元に保存し、必要に応じてご覧ください。

目次

この時計について

ソーラー充電について

電波の受信について

ワールドタイム

アラーム

ストップウォッチ

タイマー

困ったときは


English

ご使用にあたって

■ 充電を心がけましょう

エネルギー残量に注意し、【光のあたるところに置く・保管する】など日常的に十分な充電を心がけましょう。

エネルギー残量は液晶パネルの【電池残量表示】で確認できます。



→ ソーラー充電について P.8～14

■ 電波を受信するために

この時計は毎日、自動的に電波を受信します。
自動受信は午前2時から午前4時の間、1時間ごとに1回行なわれます。
受信に成功した時点で自動受信を終了します。

その時間帯は時計を身に着けずに、
窓際などの【電波を受信しやすいところ】に置き、
動かさないようにしましょう。

自動受信が成功し続けることで、
特別な操作をせずに正確な時刻表示を保ちます。

→ 電波の受信について P.15～21



目次

ご使用にあたって	2
目次	3
この時計について	4
特 長	4
各部の名称と主なはたらき	5
モードの切り替えについて	6
ホームタイムモードについて	7
ソーラー充電について	8
充電のしかた	8
充電にかかる時間のめやす	9
表示と電池残量について	10
パワーセーブについて	12
P.SAVEとSLEEP	12
過充電防止機能・使用電源について	14

電波の受信について	15
電波修正時計とは	15
電波受信のしくみ	15
電波受信のしかた	15
日本の標準電波	16
電波受信範囲のめやす	16
受信環境について	17
受信しやすくするために	17
受信しにくい環境	17
電波を受信して時刻を合わせる	18
強制受信のしかた	18
受信が作動しないときは	20
CHECK! が出たら	20
受信結果を確認する	21

ワールドタイム	22
都市名と時差について	22
ワールドタイムの使いかた	23
アラーム	24
ワンタイムアラームの使いかた	24
デイリーアラームの使いかた	25
ストップウォッチ	26
ストップウォッチの使いかた	26
タイマー	27
タイマーの使いかた	27
その他	28
メッセージ表示について	28
製品仕様	29
内部照明、液晶パネルについて	29

困ったときは	30
こんな表示のときは	30
こんなときは	31
万が一、異常な動きになったとき	34
システムリセットのしかた	34
使用上の注意とお手入れの方法	35
保管について	35
日常のお手入れ	36
かぶれやアレルギーについて	37
入浴について	37
防水性能	38
携帯上、ご注意いただきたいこと	39
定期点検について	39
修理について	39

特 長

この時計はソーラー駆動の電波修正ウォッチです。日本の電波を受信して正しい時刻を表示します。
ソーラーパネルで受けた光を「電気エネルギー」に換え、時計を動かしています。

- 電波受信…………… 毎日、自動的に電波を受信し、正しい時刻に合わせます。
→ P.15 手動で強制的に電波を受信させることもできます。
- 電波レベル表示…………… 受信中に電波の強さを表示します。
→ P.18
- 受信結果表示…………… 直近の受信結果(成否)と、
→ P.21 最後に受信に成功した日時を表示します。
- ソーラー充電…………… フル充電で約3ヶ月動き続けます。
→ P.8
- 電池残量表示…………… 電池残量をおおまかに表示します。
→ P.10
- パワーセーブ…………… 光があたらず、ボタン操作がない状態が続くと、無駄な
→ P.12 エネルギーの消費を抑えるために自動的にはたらきます。

この時計は時刻表示機能(時・分)のほかに、以下の機能を備えています。

- フルオートカレンダー 月末のカレンダーの修正が必要ありません。
(2006~2099年)
- ワールドタイム…………… 世界32都市・地域の時刻を表示します。
→ P.22
- ワンタイムアラーム… 設定した時刻に1回だけ鳴るアラームがセットできます。
→ P.24
- デイリーアラーム…………… 設定した時刻に毎日鳴るアラームがセットできます。
→ P.25
- ストップウォッチ…………… 1/100秒単位で計測できます。
→ P.26 最大計測時間は9時間59分59秒99です。
- タイマー ……………… 1分単位でセットするカウントダウンタイマーです。
→ P.27 1分~9時間59分までセットできます。


各部の名称と主なはたらき

本体

ソーラーパネル

ボタン **A**
モード切り替え

ライトボタン
内部照明の点灯



内蔵アンテナ

パネルの下に電波受信用のアンテナが内蔵されています


ボタン **B**

設定・修正: プラス(進む)
ホームタイム: 表示切り替え
STP.W: スタート/ストップ

ボタン **C**

設定・修正: マイナス(戻る)
電波: 強制受信、受信結果表示
STP.W: スプリット/リセット

液晶パネル



電池残量表示 → P.10

電波アイコン


受信結果: 成否 → P.21
受信: 電波の強さ → P.18

モードアイコン → P.6

TIME W.R.T. 1-ALM ALM STP.W TMR
現在のモードがわかります

モードの切り替えについて

ボタン **A** を押すごとにモードが切り替わります。表示最下段のモードアイコンが、現在のモードを示します。



ホームタイムモードについて

■ ホームタイムモードでの表示の切り替え

時刻・カレンダー表示



都市コード・時差表示



B 1回押し
10秒後に
自動復帰

メッセージ表示




B 長押し
B 1回押し

※ メッセージはあらかじめセットされたもののみが表示されます。

■ 各種設定のしかた

ホームタイムモード 時刻・カレンダー表示



A 長押し

A 長押し
または、1分間
ボタン操作が無いとき
設定の途中で
戻ることができます。

A 1回押し

※ この時計は日本の電波を受信するものです。
電波を受信させてお使いになるときは、ホームタイム
の都市コードをTYO(東京)に設定してください。

ホームタイム※
都市設定

A 1回押し

ホームタイムの
サマータイム
(DST)設定

A 1回押し

時刻合わせ
秒→分→時

A 1回押し

カレンダー修正
年→月→日

A 1回押し

12H/24H
表示切り替え

A 1回押し

コントラスト
設定

A 1回押し

パワーセーブ
ON/OFF
→ P.13

設定可能な部分が点滅
設定は **B** または **C** を押す

充電のしかた

■ 充電のしかた


この時計はソーラー時計です。ソーラーパネルが受けた光で発電し、電気を二次電池に蓄えながら動いています。

快適にご使用いただくために、表示をめやすに十分な充電を心がけましょう。

■ 表示と電池残量について → P.10


ソーラーパネルに
光をあてて
充電してください。

ソーラーパネル



■ 以下の場合、充電不足による電池切れが起こる可能性が高くなります

- ・ 時計を身に着けているときに、服の袖などで隠れてしまうとき
- ・ 光のあたりにくい環境での継続的なご使用や保管などが続くとき



充電にかかる時間のめやす

■ 充電にかかる時間のめやす

下記の時間を参考に、充電を行なってください。

環境(めやす)	極少	少ない	中くらい	十分	1日ぶん 動かすには
					
晴れた日の屋外 10万ルクス	約15分		約9時間	約5時間	約7分
晴れた日の窓際 1万ルクス	約1時間		約23時間	約19時間	約20分
くもりの日の窓際 5000ルクス	約2時間		約58時間	約39時間	約48分
蛍光灯の屋内 500ルクス	約28時間		—	—	約8時間

※充電に必要な時間は、モデルによって若干異なります。

この時計は、一度フル充電すると、以下の状況で使用した場合
その後充電されなくても約3ヶ月間動き続けます。


- ・ ライト点灯:2秒間(1日)
- ・ アラーム音:10秒間(1日)
- ・ 電波受信:10分間(1日)
- ・ パワーセーブ(P.SAVE):6時間(1日)

- ※ ライト(内部照明)をたくさん使うと、電池が早く減りますので
ご注意ください。
- ※ 使い始め、または充電不足で停止している時計を動かすときは
左の表を参考に十分な充電をしてください。

表示と電池残量について


■ 表示と電池残量について

パネルの表示でおおまかな電池残量がわかります。



液晶タイプでの表示の違い





※1 ③、④の状態は、光のあたらないところでは何も表示しません。


※2 ③の状態では、ストップウォッチ計測時間、タイマー設定時間がリセットされます。

パワーセーブについて(P.SAVEとSLEEP)

■ パワーセーブがはたらくと

※ P.SAVEはパワーセーブのことです。

光があたらずに、ボタン操作が一定時間以上ない状態が続くと、無駄なエネルギーの消費を防止するパワーセーブ機能(節電機能)がはたらきます。




■ パワーセーブのON/OFF

暗いところで4時間以上ストップウォッチ、またはタイマーを使うときは、パワーセーブをOFF(停止)にさせていただくことをおすすめします。

通常はパワーセーブをONにしてお使いください。

- ① P.7の「各種設定のしかた」を参照し、パワーセーブON/OFFの設定画面にします。



- ② パワーセーブを設定します



ボタンを押すごとにON/OFFが切り替わります。
ボタン **A** を押す、または
1分経つとホームタイムモードへ戻ります。

過充電防止機能・使用電源について

■ 過充電防止機能について

- ・ 二次電池がフル充電になると、それ以上充電されないように自動的に過充電防止機能がはたらきます。そのためフル充電までの所要時間を超えて充電しても、時計が破損することはありません。

※フル充電までの所要時間 → 充電にかかる時間のめやす P.9

⚠️ ご注意

■ 充電時のご注意

- ・ 充電の際、写真証明ライト、スポットライト、白熱ライト(球)などに、近づけ過ぎると、時計体が高温になり内部の部品等が損傷を受ける恐れがありますのでご注意ください。
- ・ 太陽光にて充電する際も、車のダッシュボード等では、かなりの高温となりますので、ご注意ください。
- ・ 時計体が60℃以上にならないようにしてください。

■ 使用電源について

- ・ この時計には、一般の電池とは異なる二次電池を使用しており、一般の酸化銀電池のように定期的な交換の必要はありません。
- ・ ただし、二次電池は長い期間充放電をくり返すことにより、持続時間がわずかながら短くなる場合があります。
(ご使用状態や保管場所の環境などによって異なります。)
- ・ この二次電池は環境に対して影響の少ないクリーンなものです。

⚠️ 警告


■ 二次電池について

この時計は専用の二次電池を使用しております。
専用の二次電池以外が組み込まれると、破裂、発熱、発火などの恐れがありますので、組み込まないでください

電波修正時計とは

■ 電波受信のしくみ

この時計は、正確な時刻情報をのせた標準電波を受信することにより、正しい時刻を表示する時計です。



標準電波の時刻情報は、およそ10万年に1秒の誤差という超高精度を保つ「セシウム原子時計」によるものです。

■ 電波受信のしかた

電波の受信には次の2つがあります。

■ 自動受信：毎日、自動的に電波を受信します

自動受信は午前2時から午前4時の間、1時間ごとに1回行なわれます。受信に成功した時点で自動受信を終了します。

- ※ 自動受信はホームタイムモード、またはワールドタイムモードのときにはたります。それ以外のモードでは受信しませんのでご注意ください。
- ※ システムリセットをすると、1分後に自動受信が始まります。

■ 強制受信：手動で強制的に電波を受信させることができます


- ※ 強制受信はホームタイムモードのときに機能します。それ以外のモードでは機能しません。

受信の成否は受信環境によって左右されます。環境によっては、正確に電波が受信できないことがあります。受信ができているかどうかは【受信結果】を見て確認しましょう。

■ 日本の標準電波

この時計は、日本の標準電波を受信することができます。

ホームタイムの都市コードが、TYO(東京)、SEL(ソウル)、HKG(香港)に設定されているときに受信の機能がはたらきます。



【日本の標準電波：JJY】

情報通信研究機構により運用されています。国内2ヶ所の送信所から、それぞれ異なる周波数で送信されています。

- ・ 福島送信所: おおたかどや山: 40kHz
- ・ 九州送信所: はがね山: 60kHz

受信範囲のめやすは、
各送信所を中心に半径約1,000 kmです。

⚠️ ご注意

■ 電波受信について

- ・ 電波障害などにより誤った受信をしたときは、誤った時刻を表示する場合があります。また、受信場所・電波状況によっては受信できないことがあります。このようなときは、受信を行なう場所を変えてお使いください。
- ・ 標準電波の特性により、夜間のほうがより受信しやすくなります。
- ・ 電波が受信できない場合でもクォーツの精度（平均月差±30秒）で動いてます。
- ・ 設備のメンテナンスや落雷の影響などにより停波（電波停止）することがあります。停波に関する情報は、各送信所のホームページをご覧ください。弊社お客様相談窓口にお問い合わせください。
- ・ 送信所のホームページアドレス（2006年8月現在）
NICT 独立行政法人 情報通信研究機構（日本標準時グループ）<http://jjy.nict.go.jp/>
- ・ セイコーウオッチ（株）お客様相談窓口（全国フリーダイヤル）0120-612-911

※ 受信の成否は天候や受信環境によって左右されます。

※ 受信範囲の外では受信できません。

受信環境について

■ 受信しやすくするために



時計を、窓際などの電波が受信しやすい場所に置いてください。

安定した状態で電波を受信するために、受信中は時計の向きを変えたり、傾けたりなど、動かさずに静止した状態にしてください。


この時計には、電波を受信するためのアンテナが内蔵されています。アンテナは時計の12時の位置にあります。

■ 受信しにくい環境




- ・テレビ、冷蔵庫、エアコンなど家電製品の近く
- ・携帯電話、パソコン、FAXなどOA機器の近く
- ・スチール机などの金属製の家具の上や近く

このような場所を避けて受信を行ってください。



- ・ビルの中、ビルの谷間や地下



- ・高圧線やテレビ塔、電車の架線の近く



- ・工事現場、交通量の多い場所など、電波障害の起こる所



- ・乗り物の中（自動車、電車、飛行機など）

電波を受信して時刻を合わせる（強制受信のしかた）

① 時計を置く



時計を腕からはずし、窓際などの電波を受信しやすい場所に置きます。

② ボタンCを2秒以上押す



ボタンCを押すと上の【RECEIVE】の表示になります。

ホームタイムモードの時刻表示の状態、ボタンCを2秒以上押し続けます。

※ ホームタイム以外のモードでは受信できません。

③ 時計を置いたまま、しばらく待つ

受信には最長13分かかります

電波の強さが4段階で表示されます。（毎秒更新）



電波レベル表示




受信中を表すアニメーションが流れます。

受信が終わるまで時計を動かさずに待ちます。
時計を持って傾けたりせず、静止させた状態で置いたままお待ちください。

※ 受信中にいずれかのボタンを押すと、受信がキャンセルされます。

④ 受信の結果を確認



受信が終わると表示で知らせます。表示は10秒間続きます。
10秒経過、またはボタンCを1回押すとホームタイムモードに戻ります。

- ※ 受信の成否は天候や受信環境によって左右されます。
- ※ 受信範囲の外では受信できません。

受信がうまくいかないときは、
時計を置く場所や向きを変えてみましょう。また、同じ
場所でも時間帯によって受信環境は異なります。電波の
特性により、夜間のほうがより受信しやすくなります。

このメッセージが出たときは

CHECK!

受信ができない設定になっています。
設定の解除は次のページへ

受信が作動しないときは(CHECK! が出たら)


このメッセージが出たときは

CHECK!

右の3つの状態が考えられます。
右図にしたがって解除しましょう。

表示は10秒経過、またはボタン **C** を1回押すと
ホームタイムモードに戻ります。

①





STPW が点滅:ストップウォッチが動いています
ストップウォッチを止めてください。
→ ストップウォッチの使いかた P.26

②



TMR が点滅:タイマーが動いています
タイマーを止めてください。
→ タイマーの使いかた P.27

③



ホームタイムの都市設定が違ってしています。
ホームタイムをTYO(東京)、または
SEL(ソウル)、HKG(香港)にしてください。
→ 各種設定のしかた P.7


この3つの状態が重なっていることがあります。

※ この時計は日本の電波を受信するものです。

受信結果を確認する

■ 受信結果の確認


直近の受信結果(成否)が確認できます。
どのモードのときでも表示されています。



※ ホームタイムモードで各種設定のモードに入ると、
直近の受信結果がリセットされ「表示なし」の状態になります。

■ 最後に受信に成功した日時を確認


① ボタンCを1回押す



ホームタイムモードの状態で、
ボタンCを1回押します。

※ ①でボタンを2秒以上押し続けると、受信の動作に入ります。
受信の動作をキャンセルするには、いずれかのボタンを押してください。

② 受信に成功した日時を表示



例：12月8日午前3時10分に受信成功

表示は1分経過、またはボタンCを1回押すと
ホームタイムモードに戻ります。

都市名と時差について

都市コード	都市名	国・地域	UTCからの時差
UTC	-----	協定世界時	-----
LON	ロンドン★	イギリス	0時間
PAR	パリ★	フランス	1時間
BER	ベルリン★	ドイツ	1時間
ATH	アテネ★	ギリシャ	2時間
CAI	カイロ★	エジプト	2時間
MOW	モスクワ★	ロシア	3時間
BGW	バグダッド	イラク	3時間
THR	テヘラン★	イラン	3.5時間
DXB	ドバイ	アラブ首長国連邦	4時間
KBL	カブール	アフガニスタン	4.5時間
KHI	カラチ	パキスタン	5時間
DEL	デリー	インド	5.5時間
DAC	ダッカ	バングラデシュ	6時間
RGN	ヤンゴン	ミャンマー	6.5時間
BKK	バンコク	タイ	7時間

都市コード	都市名	国・地域	UTCからの時差
HKG	香港	中国	8時間
SEL	ソウル	韓国	9時間
TYO	東京	日本	9時間
ADL	アデレード★	オーストラリア	9.5時間
SYD	シドニー★	オーストラリア	10時間
NOU	ヌーメア	ニューカレドニア	11時間
WLG	ウェリントン★	ニュージーランド	12時間
HNL	ホノルル	アメリカ	-10時間
ANC	アンカレッジ★	アメリカ	-9時間
LAX	ロサンゼルス★	アメリカ	-8時間
DEN	デンバー★	アメリカ	-7時間
CHI	シカゴ	アメリカ	-6時間
NYC	ニューヨーク★	アメリカ	-5時間
CCS	カラカス	ベネズエラ	-4時間
RIO	リオデジャネイロ★	ブラジル	-3時間
PDL	アゾレス諸島★	アゾレス諸島	-1時間

★印の地域ではサマータイムが導入されています。(2006年8月現在)

※ 各地域の時差、及びサマータイムは、国または地域の都合により変更される場合があります。

ワールドタイムの使いかた

WRT 世界各地の時刻を知る

世界32都市・地域の時刻を知ることができます。

- ① P.6の「モードの切り替えについて」を参照し、ワールドタイムモードにします。

※ ワールドタイムモードに切り替えると、前回このモードで見た都市の時刻を表示します。

■ 協定世界時(UTC:Coordinated Universal Time)

UTCは国際協定により人工的に維持されている世界共通の標準時です。全世界で、時刻を記録する際の公式な時刻として使われています。

■ サマータイム(DST:Daylight Saving Time)

サマータイムは夏時間のことで、夏の日照時間の長いときに、時刻を1時間進めて昼間の時間を長くする制度です。国や地域によって、個別にサマータイムが設定されており、欧米を中心に世界の約80ヶ国で実施されています。サマータイムの実施期間や実施地域は国によって様々です。



- ② 都市・地域を選択します

ボタン **B**
プラス(進む)


1回押し: 1つ送り
長押し: 早送り

ボタン **C**
マイナス(戻る)

- ③ 必要に応じて、サマータイム(DST)を設定します

ボタン **A**
ON/OFF
長押し

DST
マークが
つきます



ワンタイムアラームの使いかた

1-ALM ワンタイムアラームを使う

設定した時刻に1回だけ鳴るアラームがセットできます。

- ① P.6の「モードの切り替えについて」を参照し、ワンタイムアラームモードにします。

② アラーム時刻を設定します


B プラス
(進む)

1回押し: 1分送り
長押し: 15分送り

C マイナス
(戻る)


設定のキャンセル
ボタン**B**と**C**同時押し

※ 設定中に、アラーム時刻が現時刻と同じになると、設定がリセットされ、表示が「-:-」になります。



③ アラームを設定すると

設定後は、どのモードでも
ワンタイムアラームマークが表示されます



設定した時刻になるとアラーム音が10秒間鳴り、
表示が「-:-」に戻ります。

アラーム音をすぐに止めたいときは、
いずれかのボタンを押してください。

- ※ このモードでは電波の受信はできません
- ※ 電波の受信中にアラーム音が鳴ると、受信を中止します。

デイリーアラームの使いかた

ALM デイリーアラームを使う

設定した時刻に毎日鳴るアラームがセットできます。

- ① P.6の「モードの切り替えについて」を参照し、
デイリーアラームモードにします。

※ デイリーアラームモードに入ると、前回アラーム設定した時刻が表示されます。

② アラーム時刻を設定します

A 長押し
設定モード
に入る

B または **C**
時設定
(時が点滅)

A
切り替え
(時→分)

B または **C**
分設定
(分が点滅)


A
設定
モード
終了

ボタン**B**と**C**の操作
1回押し: 1つ送り
長押し: 早送り
離すと停止



③ アラームのON/OFF

ボタン**B** またはボタン**C** を押すと
ON/OFFが切り替わります。



ONにすると、どのモードでも
デイリーアラームマークが表示されます。

※ ボタン**C**を長押しすると、アラーム音が
試聴できます。(10秒間)

アラーム音を止めるには、
いずれかのボタンを押してください。

※ このモードでは電波の受信はできません


※ 電波の受信中にアラーム音が鳴ると、受信を中止します。

ストップウォッチの使いかた

STEP Ⅲ ストップウォッチを使う

1/100秒単位で計測できます。
最大計測時間は9時間59分59秒99です。

- ① P.6の「モードの切り替えについて」を参照し、ストップウォッチモードにします。



※ このモードでは電波の受信はできません

※ ストップウォッチの動作中は、電波の受信ができません

② -1: 通常の計測




※ 暗いところで1時間以上
ストップウォッチを使うときは、
パワーセーブをOFF(停止)にする
ことをおすすめします。
パワーセーブのON/OFF → P.13

② -2: スプリットタイム(途中経過時間)の計測



スプリットタイムは
5秒間表示されます。

例: 地点通過時の計測 【スタート→A地点→B地点→ゴール】の各タイム計測



タイマーの使いかた

TMR タイマーを使う

1分単位で、1分～9時間59分までセットできます。

- ① P.6の「モードの切り替えについて」を参照し、タイマーモードにします。

※ タイマーモードに入ると、前回タイマー設定した時間が表示されます。

- ② タイマー時間を設定します

A 長押し
設定モード
に入る

B または **C**
時設定
(時が点滅)

A
切り替え
(時→分)


B または **C**
分設定
(分が点滅)

A
設定
モード
終了

ボタン **B** と **C** の操作
1回押し: 1つ送り
長押し: 早送り
離すと停止

※ このモードでは電波の受信はできません

※ タイマーの動作中は、電波の受信ができません



- ③ タイマーを動かします

停止3秒前から1秒ごとに
アラーム音が鳴ります。
カウントゼロで5秒間鳴り続けます。
タイマーはカウントゼロで停止し、
セットした時間に戻ります。

アラーム音を止めるには、
いずれかのボタンを押してください。

※ リセット(ボタン **C**)を押すと、セットした時間に戻ります。

※ 暗いところで1時間以上タイマーを使うときは、
パワーセーブをOFF(停止)にすることをおすすめします。
パワーセーブのON/OFF → P.13

メッセージ表示について

■ メッセージ表示について

この時計は、各仕様に固有のメッセージを表示します。

メッセージはあらかじめセットされたものが表示されます。

オリジナルメッセージの作成はできません。

- ① ホームタイムモードの状態
でボタン **B** を長押しします。



- ② メッセージが表示されます



例：メッセージが【 WIRED 】の場合

メッセージは、スクロールした後に止まります。
ボタン **B** を押すとホームタイムモードへ戻ります。

■ 製品仕様

※ 製品仕様は改良のため、予告なく変更することがあります。

1. 水晶振動数…… 32,768Hz (Hz = 1秒間の振動数)
2. 精度…………… 平均月差±30秒
(電波受信による時刻修正が行われない場合、
かつ気温5℃～35℃において腕に着けた場合)
3. 作動温度範囲…… -5℃～+50℃ (ただし表示機能は0℃～+50℃)
4. 表示体…………… FE (電界効果)型ネマチック液晶
5. 使用電源…………… 二次電池: 1個
6. 持続時間…………… 約3ヶ月(フル充電後に光があたらず、1日あたりEL 1回(2秒間)、
アラーム音1回(10秒間)、電波受信1回(10分間)、
パワーセーブ6時間で使用した場合)
※フル充電をした状態からパワーセーブが作動した場合は最大約9ヶ月
7. 電波受信機能…… 自動受信: 午前2時
(受信できなかった場合、午前3時、4時に再受信)
※受信から次の受信までは上記クォーツの精度で動く
※強制受信機能付
8. 内部照明…………… EL (エレクトロルミネッセンス)
9. 電子回路…………… 発振、分周、駆動、受信、EL回路: C-MOS-IC 3個

■ その他

■ 内部照明(EL:エレクトロルミネッセンス)について

内部照明として使用されているエレクトロルミネッセンス(EL)パネルは、電池の電圧が低くなると、輝度(明るさ)が低下します。また、ELパネルは発光時間の経過と共に、徐々に輝度が減衰する特性を持っています。

※ELパネルの輝度は、点灯時間の累積で約120時間経過すると半減します。使用中に内部照明が暗くなったときは、まず十分に充電してください。十分に充電しても暗すぎる場合は、ELパネルの交換となります。お買い上げ店に交換をお申しつけください。有料にて申し受けます。


■ 液晶パネルについて

この時計の〈液晶パネル〉は、5年を過ぎますとコントラストが低下したり、数字が読みにくくなります。お買い上げ店に交換をお申しつけください。有料にて申し受けます。

こんな表示のときは

下のような表示になったときは、それぞれの案内を参照ください。


ピー・セーブ



パワーセーブが
はたらいている

→ P.12


スリープ



パワーセーブが
はたらいている

→ P.12


チェック!



受信ができない
設定になっている

→ P.20

チャージ



電池残量が少なく
なっている

→ P.11

何も表示されていない



電池残量が少なく
なっている

→ P.11

表示が全て点灯している



ホームタイムモード
の各種設定で
ボタン **B** と **C** を
同時に押した

→ いずれかのボタン
を押すとホームタイム
モードに復帰します

こんなときは

現 象		考えられる原因	このようにしてください
電波の受信	受信できない	受信中に時計を動かした	受信中は時計を動かさないようにしてください。(向きを変える、傾ける＝動かす) 詳しくは「受信しやすくするために P.17」を参照ください。
		受信中にキャンセルをした	受信中にいずれかのボタンを押すと、受信がキャンセルされます。(自動受信、強制受信ともに)
		受信している場所の電波が弱い 電波の届かない環境にある	受信しやすい環境に時計を置きなおして受信を試みましょう。 詳しくは「受信しにくい環境 P.17」を参照ください。
		標準電波送信所の都合で 電波を止めている(停波)	停波に関する情報は送信所を運営する機関のホームページを参照ください。 ホームページのアドレスについてはP.16を参照ください。 詳しくは「電波の受信について P.15」を参照ください。
		ストップウォッチ、または タイマーが作動中である	ストップウォッチ、タイマー(またはその両方)を止めてください。 詳しくは「受信が作動しないときは P.20」を参照ください。
		ホームタイムに、受信機能がはた らかない都市コードが選択されて いる	電波を受信させてお使いになるときは、ホームタイムの都市設定を、TYO(東京) またはSEL(ソウル)、HKG(香港)に設定してください。 詳しくは「受信が作動しないときは P.20」を参照ください。

こんなときは

現 象		考えられる原因	このようにしてください
時刻のずれ	時計が一時的に進む、または遅れる	外部からの影響で間違った時刻を受信した(誤受信)	より受信しやすい環境で受信するようにしてください。 必要に応じて強制受信をしてください。 詳しくは「受信しにくい環境 P.17」、「強制受信のしかた P.18」を参照ください。
		時計を暑いところ、または寒いところに放置した	常温に戻れば元の精度に戻ります。 必要に応じて強制受信をしてください。 詳しくは「強制受信のしかた P.18」を参照ください。 元に戻らない場合は、お買い上げ店にご相談ください。
	時刻が1時間単位でずれている	ホームタイムの都市設定が表示させたいものと違う都市・地域になっている	ホームタイムの都市設定を確認し、設定しなおしてください。 日本時間を表示させたいときは都市設定をTYO(東京)にしてください。 詳しくは「各種設定のしかた P.7」を参照ください。
		ホームタイムにサマータイム(DST)が設定されている	ホームタイム時刻表示の左下にDSTと表示されていると、サマータイムが設定されています。 サマータイム設定が必要でないときは、サマータイムをOFFにしてください。 詳しくは「各種設定のしかた P.7」を参照ください。

現 象		考えられる原因	このようにしてください
充 電	止まっていた時計を、「フル充電までの所要時間」を超えて充電しても作動しない	あてる光が弱い、充電中に光のあたりかたが変わった	光のあたりかたが変わらないように配慮して、十分な明るさのある環境で充電してください。
		時計内部のシステムが不安定になっている	システムリセットをしてください。 詳しくは「システムリセットのしかた P.34」を参照ください。
操 作	ボタンを押しても反応しない	電池残量が少なくなっている	「表示と電池残量について P.10」を参照のうえ、充電をしてください。
表 示	何も表示されない		
その他	ガラスのくもりが消えない	パッキンの劣化などにより時計内部に水が入った	お買い上げ店にご相談ください。

※このほかの現象についてはお買い上げ店、またはお客様相談室にご相談ください。

万が一、異常な動きになったとき

■ システムリセットのしかた

万が一異常な動きになったときは、システムリセットをすることで正常に機能するようになります。

- ① ボタン **A B C** を同時に長押しし、表示が消えたら離します。



リセットされます



表示がない状態から復帰するとホームタイムモードの時刻表示になります。

時刻、カレンダーは2006年1月1日、日曜日、AM12時00分00秒からカウントを始めます。

1分後に自動受信が始まります。

- ② 電波受信ができなかったときは、強制受信または手動で時刻を合わせてください。


■ 強制受信のしかた → P.18

■ 各種設定のしかた（時刻合わせ）→ P.7

※ 復帰後はホームタイム、ローカルタイムともに日本時間（都市コード：TYO）になります。


使用上の注意とお手入れの方法

■ 保管について



- ・「 -5°C ～ $+50^{\circ}\text{C}$ からはずれた温度」では、機能が低下したり、停止する場合があります。

※この時計は常温（ 5°C ～ 35°C の範囲内）で腕に付けた時に安定した精度を得られるように調整してあります。したがって、温度によって多少の進み遅れが生ずることがありますが、常温に戻れば元の精度にもどります。



- ・磁気や静電気の影響があるところに放置しないでください。



- ・強い振動のあるところに放置しないでください。
- ・極端にホコリの多いところに放置しないでください。



- ・薬品の蒸気が発散しているところや薬品にふれるところに放置しないでください。（薬品の例：ベンジン、シンナーなどの有機溶剤、及びそれらを含むもの－ガソリン、マニキュア、化粧品などのスプレー液、クリーナー剤、トイレ用洗剤、接着剤など－水銀、ヨウ素系消毒液など）
- ・温泉や防虫剤の入ったひきだしなど特殊な環境に放置しないでください。

使用上の注意とお手入れの方法

⚠️ ご注意

■ 日常のお手入れ

ケース・バンドは肌着類と同様に直接肌に接しています。汚れたままにしておくとサビて衣類の袖口を汚したり、かぶれの原因になることがありますので常に清潔にしてご使用ください。


時計をはずしたときには、柔らかい布などで汗や水分を拭き取ってください。汚れも取れ、ケース、バンド、およびパッキンの寿命が違ってきます。

金属バンド

金属バンドは時々柔らかい歯ブラシなどを使い、石けん水で部分洗いなどのお手入れをお願いします。その際に、非防水の時計の場合には時計本体に水がかからないようにご注意ください。

革バンド

革バンドは水分を吸い取るように軽く拭いてください。こするように拭くと色が落ちたり、ツヤがなくなったりする場合があります。



軟質プラスチックバンド

ウレタンバンドなど軟質プラスチックでできているバンドは、蛍光灯や太陽光の下に長時間放置されたり、汚れが染み込んだりすることによって、色あせ・変色、あるいは硬くなったり切れたりする場合があります。特に半透明のウレタンバンドは、変色などが目立ちやすく、条件によっては数ヵ月のご使用で起こり始める場合があります。湿気の多い場所に保管したり、汗や水で濡れたまま放置しておくと、早く変色することがありますので、汚れたときは、石けん水で洗ってください。ただし、化学製品ですので溶剤によっては変質する場合があります。

- 非防水時計は、水（水道の水はね、雨、雪など）や多量の汗にご注意ください。万一、水や汗でぬれた場合には吸湿性のよい布などで水分を拭きとってください。
- 日常生活用強化防水時計は海水中などでの使用のあと、化学薬品類を使用せず、ためた真水で洗ってください。
- 回転ベゼル付きの時計の場合、ベゼル下に汚れなどがたまり、回転が重くなったりしますので清潔にしてご使用ください。

⚠️ ご注意**■ かぶれやアレルギーについて**

- ・バンドは多少余裕を持たせ、通気性を良くしてご使用ください。
- ・かぶれやすい体質の人や体調によっては、皮膚にかゆみやかぶれをきたすことがあります。
- ・かぶれの原因として考えられるのは以下の2つです。
 1. 金属・皮革に対するアレルギー
 2. 時計本体及びバンドに発生した錆、汚れ、付着した汗
- ・万が一、肌などに異常を生じた場合は、ただちに使用を中止し医師にご相談ください。

⚠️ ご注意

提げ時計やペンダント時計の場合、ひもやチェーンによって衣類や手・首などを傷つける事がありますのでご注意ください。

⚠️ 警告

- ・日常生活用防水（3気圧）の時計は水の中に入れてしまうような環境での使用はできません。
- ・日常生活用強化防水（5気圧）の時計は、スキンドビングを含めて全ての潜水に使用できません。
- ・日常生活用強化防水（10・20気圧）の時計は、飽和潜水／空気潜水には使用できません。

■ 入浴について

- ・10気圧以上の防水の場合、時計をつけたまま入浴してもかまいませんが、下記のことにご注意して下さい。
- ・時計に、石けんやシャンプーがついた状態で、りゅうず操作やボタン操作を行わないでください。（防水機能が維持できなくなることがあります）
- ・温水で時計が温まると、多少の進み、遅れを生ずることがあります。ただし、常温にもどれば精度はもとにもどります。

使用上の注意とお手入れの方法

⚠️ ご注意

■ 防水性能

- ・時計の文字板または裏ふたにある防水性能表示をご確認の上、使用可能範囲にそって正しくご使用ください。
- ・水分のついたまま、りゅうずを回したり引き出したりしないでください。時計内部に水分が入ることがあります。

							
非 防 水			洗顔や雨など一時にかかる水滴	水泳や水仕事など長時間水にふれる場合	空気ポンベを使用しない潜水(スキング)や入浴	空気ポンベやヘリウムガスなどを使用する本格的な潜水	水滴がついた状態でのボタン操作
日常生活用防水			×	×	×	×	×
日常生活用強化防水	5気圧防水	ケースの裏にWATER RESISTANTの表示のある時計	○	×	×	×	×
	10・15・20気圧防水	ケースの裏にWATER RESISTANT 5・10・15・20BARか、WATER RESISTとマークの表示のある時計	○	○	×	×	○

■ その他、携帯上で注意いただきたいこと

- ・バンドの着脱の際に中留などで爪を傷つける恐れがありますのでご注意ください。
- ・転倒時や他人との接触などにおいて、時計の装着が原因で思わぬケガを負う場合がありますのでご注意ください。
- ・特に乳幼児を抱いたりする場合は、時計に触れることでケガを負ったり、アレルギーによるかぶれをおこしたりする場合がありますので十分ご注意ください。

■ 定期点検について

- ・ながくご愛用いただくために、2～3年に一度程度の点検調整をおすすめします。定期的な点検により目に見えない部分が原因となる損傷を未然に防ぎ、より安心してご使用いただけます。保油状態・漏液の有無・汗や水分の侵入などの点検をお買い上げ店でご依頼ください。点検の結果によっては分解掃除を必要とする場合があります。
- ・部品（電池）交換の時は、「純正部品（電池）」とご指定ください。電池が切れたまま長時間放置しますと漏液などで故障の原因となりますので早めに交換をご依頼ください。
- ・定期点検や電池交換の際には、パッキンやバネ棒の交換もあわせてご依頼ください。



■ 修理について

1. 保証内容は保証書に記載したとおりですので、よくお読みいただき大切に保管してください。
2. この時計の補修用性能部品の保有期間は通常7年間を基準としています。正常なご使用であれば、この期間中は原則として修理可能です。
（補修用性能部品とは、時計の機能を維持するのに不可欠な修理用部品です。）
3. 修理可能な期間はご使用条件によりいちじるしく異なり、精度が元通りにならない場合がありますので、修理ご依頼の際にお買い上げ店とよくご相談ください。
4. 修理のとき、ケース・文字板・針・ガラス・バンドなどは一部代替部品を使用させていただいたり、またはケースごとの一式交換や代替品に替わることがありますので、ご了承ください。
5. 修理の内容によっては、修理代が標準小売価格を上まわる場合があります。その他、わからない点がありましたら「セイコーウオッチ株式会社お客様相談室・お客様相談係」へお問い合わせください。

Consult the retailer from where you purchased the watch for repair or assistance with SEIKO products.
Should you have any questions, please contact the SEIKO CUSTOMER SERVICE CENTER listed below.

● SEIKO CUSTOMER SERVICE CENTER

2-1-10, Kaji-cho, Chiyoda-ku, Tokyo (03) 3535-2211

8th floor, Osaka Yotsubashi Shinmachi building (06) 6538-6541

4-24, Shinmachi 1-Chome, Nishi-ku, Osaka-shi

SEIKO CUSTOMER SERVICE CENTER: 0120-612-911

(toll free in Japan, automatically connected to one of the above listed Seiko Service Centers, close to where you are)

SEIKO WATCH CORPORATION

Head Office

2-1, Shibaura 1-chome, Minato-ku, Tokyo 105-8467

WIRED DIGITAL

INSTRUCTION

WIRED W36 Series

Thank you very much for choosing a WIRED DIGITAL W36 Series Watch.

Please read carefully the instructions in this booklet for proper and safe use of your WIRED watch before start using it, and keep this manual handy for easy reference.

CONTENTS

ABOUT THIS WATCH

CHARGING THE SOLAR BATTERY

SETTING THE TIME BY RECEIVING RADIO SIGNAL

WORLD TIME

ALARM

STOPWATCH

TIMER


TROUBLESHOOTING

BEFORE USE

■ Make sure to keep the watch sufficiently charged

Check the amount of energy stored in the watch's battery and place or store in a location receiving light, etc., to sufficiently charge the battery with electricity.

The amount of energy stored in the watch can be checked by "Display and Remaining Battery Amount."



→ CHARGING THE SOLAR BATTERY P.45~54


■ To receive radio signals

This watch automatically receives radio signals to adjust the time every day. Automatic reception is performed every hour from 2 AM to 4 AM.

Automatic reception ends upon completion of satisfactory reception.

During this period of time, place the watch in a location that easily receives radio signals without wearing it and do not move it.

As long as automatic radio signal reception is successful, the watch will keep the precise time without any special operation by the user.



→ SETTING THE TIME BY RECEIVING RADIO SIGNAL P.55~61

CONTENTS

BEFORE USE	42
CONTENTS	43
ABOUT THIS WATCH	44
Features	44
Name and Function of Each Part	45
Mode switching	46
Home time mode	47
CHARGING THE SOLAR BATTERY	48
How to Charge	48
Reference for Time Required to Charge ...	49
Display and Remaining Battery Amount ...	50
Power Save	52
P.SAVE and SLEEP	52
Overcharge Prevention Function and Power Source	54

SETTING THE TIME BY RECEIVING RADIO SIGNAL ..	55
What is a Radio-Controlled Watch ?	55
What is a radio-controlled watch?	55
How to receive radio signals	55
Official standard frequency of Japan (JJY) ...	56
Reception range of each standard frequency	56
Appropriate Place to Keep a Radio-Controlled Watch	57
To enable the watch to receive radio signals easily	57
Conditions in which the watch may be unable to receive radio signals	57
Adjust the Time by Receiving Radio Signals	58
How to Carry Out Manual Reception	58
When reception is not operated	60
If CHECK! is displayed	60
Confirm Reception Result	61

WORLD TIME.....	62
World Main Area Time Zone List	62
How to Use World Time	63
ALARM	64
How to Use the Single-Time Alarm ...	64
How to Use the Daily Alarm	65
STOPWATCH	66
How to Use the Stopwatch	66
TIMER	67
How to Use the Timer	67
OTHERS	68
About Massage Display	68
Specifications	69
Built-in Illuminating Light	69
The Electroluminescent Panel	69

TROUBLESHOOTING	70
When the Following Messages are Displayed	70
Troubleshooting	71
Abnormal Display or Improper Function	74
How to Reset the Built-in IC	74
CARE OF YOUR WATCH	75
Place to keep your watch	75
Care of Your Watch	76
Rash and allergy	77
About Bathing	77
Water Resistance	78
Precautions on Wearing Your Watch ..	79
Periodic Check	79
Notes on the Replacement Parts	79

Features

This is a solar radio-controlled watch. The watch receives official standard frequencies of Japan (from either of two transmitting stations) to display correct time. A solar cell underneath the dial converts any form of light into "electrical energy" to operate the watch.

- Automatic Time Setting..... The watch maintains the precise time by automatically receiving radio signals on the official standard frequency of Japan. It is also possible to make the watch manually receive radio signals.
→ P.55
- Display of Radio Signal Reception Level •• During reception attempts, the watch displays the strength of radio wave signals.
→ P.58
- Display of Radio Signal Reception Result •• The latest reception result (success/failure) and the date and time for which the latest reception was successfully performed can be confirmed.
→ P.61
- Solar Rechargeable Battery..... Once fully charged, the watch continues to run for approximately 3 months.
→ P.48
- Display of Remaining Battery Amount..... The approximate amount of energy stored in the watch's battery can be displayed.
→ P.50
- Power Save..... The Power Save mode can be activated in order to reduce unnecessary energy consumption when the watch is left without an adequate light source.
→ P.52

This watch is equipped with the following functions in addition to the time (hour and minute) display.

- Automatic calendar..... The calendar automatically adjusts for odd and even months including February of leap years from January 1, 2006 to December 31, 2099.
- World Time The watch displays the time for 32 cities and regions all over the world.
→ P.62
- Single-Time Alarm Function An alarm that sounds only one time at the set time can be set.
→ P.64
- Daily Alarm Function An alarm that sounds everyday at the set time can be set.
→ P.65
- Stopwatch Time can be measured in 1/100 sec increments. The maximum measurement time is 9 hours 59 min 59.99 sec.
→ P.66
- Timer The countdown timer can be set from 1 min to 9 hours 59 min by the minute.
→ P.67


Name and Function of Each Part

Main body

Solar panel

Button A
Mode change

Light button
Lighting of built-in illuminating light



Built-in antenna

An antenna for radio signal reception is built in under the panel.


Button B

Setting and adjustment : Plus (advance)
Home time : Display change
STP.W : Start/Stop

Button C

Setting and adjustment: Minus (Return)
Radio signal: Manual reception,
reception result display
STP.W: Split/reset

Liquid Crystal panel



→ P.50

Remaining battery level

Radio signal icon


Reception result:
Success/Failure
→ P.61
Receiving: Strength
of radio signal
→ P.58

Mode icon → P.46

TIME W.R.T. 1-ALM ALM STP.W TMR
Indicates the current mode.


Mode switching

Each pressing of button **A** changes the mode. The mode icon at the bottom indicates the current mode.




Home time mode

■ Display change on the home time mode



※ Only previously set messages are displayed.

■ Various Settings



※ This watch receives the official standard frequency of Japan. When using your watch by receiving radio signals, set the home time city code to TYO (Tokyo).

How to Charge

■ How to charge


This watch is a solar watch. This watch operates while generating electric power from light received on the solar panel and saving the electric power in the secondary battery.

Please remember to sufficiently charge the battery with reference to the display for proper use.

■ Display and remaining battery amount → P.50


Charge the battery by applying light to the solar panel.

Solar panel



■ In the following cases, there is a high likelihood that the battery may run out due to battery shortage.

- A sleeve covers your watch while you are wearing it.
- Continuously use or store in an environment where light is not likely to enter.



Reference for Time Required to Charge

■ Reference for time required to charge

Charge the battery with reference to the times listed in the table.

Environment (reference)	Extremely low	Low	Medium level	Sufficient	Required time to operate all day long
					
Outdoors on a clear day One hundred thousand lux	Approximately 15 minutes	Approximately 9 hours	Approximately 5 hours	Approximately 7 minutes	
Window side on a clear day Ten thousand lux	Approximately 1 hour	Approximately 23 hours	Approximately 19 hours	Approximately 20 minutes	
Window side on a cloudy day Five thousand lux	Approximately 2 hours	Approximately 58 hours	Approximately 39 hours	Approximately 48 minutes	
Indoor under fluorescent lamp Five hundred lux	Approximately 28 hours	—	—	Approximately 8 hours	

※Time required to charge varies depending on the model.

This watch which is fully charged once continues operating for approximately 3 months when used under the following conditions even if it is not charged thereafter.

- Lighting: 2 sec. (One day)
- Alarm sound: 10 sec. (One day)
- Radio signal reception: 10 min (One day)
- Power save (P.SAVE): 6 hours (One day)

- ※ Because the battery runs out fast if it is used frequently, limit your use of the light function (built-in illuminating light).
- ※ When operating your watch for the first time or if your watch has stopped due to battery shortage, charge the battery sufficiently according to the table on the left.

Display and Remaining Battery Amount

■ Display and remaining battery amount

The panel display indicates approximately the remaining battery amount.

Liquid Crystal panel display

1



2



Remaining battery amount



Sufficient



Medium level



Remedies


Please use your watch as it is.

Please remember to charge the battery.

■ How to Charge → P.48

Difference in the display according to the liquid crystal type





※1 Nothing is displayed in a place without light under conditions ③ and ④.


※2 Stopwatch measured time and timer setting time are reset under condition ③.

Power Save (P.SAVE and SLEEP)

■ If the P.SAVE functions

※ P.SAVE means power save.

If button operation is not performed over a predetermined time without light, the P.SAVE (power save function) functions to prevent useless consumption of energy.




■ P.SAVE ON/OFF

When using the stopwatch or timer function for over 4 hours in a dark place, it is recommended to turn off (stop) the P.SAVE.

Turn on the P.SAVE before normal use.

- ① According to "Various Settings" on P.47, display the P.SAVE ON/OFF setting screen.



- ② Set the P.SAVE.



Each pressing of the button switches ON/OFF.
Press button **A** , or in one minute,
the mode is reset to the home time mode.

Overcharge prevention function and Power Source

■ Overcharge prevention function

- When the secondary battery is fully charged, the overcharge prevention function is automatically activated to avoid further charging. There is no need to worry about damage caused by overcharging no matter how much the secondary battery is charged in excess of the time required for fully charging the watch.

※To check the time required for fully charging the watch

→ Reference for Time Required to Charge P.49

NOTICE

■ Notes on charging the watch

- When charging the watch, do not place the watch in close proximity to an intense light source such as lighting equipment for photography, spotlights or incandescent lights, as the watch may be excessively heated resulting in damage to its internal parts.
- When charging the watch by exposure to direct sunlight, avoid places that easily reach high temperatures, such as a car dashboard.
- Always keep the watch temperature under 60°C.

■ Power Source

- The battery used in this watch is a special secondary battery, which is different from ordinary batteries. Unlike an ordinary silver oxide battery, the secondary battery does not require periodic replacement.
- However, for the secondary battery, the battery characteristic changes due to repeated charge and discharge over a long time, and the duration may be shortened. (It varies depending on use condition and storage place environment.)
- The secondary battery is an environmentally friendly, clean energy storage device.

Warning


■ The battery used in this watch is a special secondary battery.

When replacing the secondary battery, make sure to install the exclusive SEIKO secondary battery for this watch. Installation of any other battery can generate heat that can cause bursting or ignition.

What is a Radio-Controlled Watch?

■ What is a radio-controlled watch?

The radio-controlled watch displays the precise time and date by automatically receiving and synchronizing itself with an accurate time signal transmitted by an official standard frequency.



Time signal transmitted by a standard frequency is based on a super accurate "Cesium Atomic Clock" that may have a 1 second loss or gain per one hundred thousand years.

■ How to receive radio signals

The following two methods are employed for radio signal reception.

- **Automatic reception:** Daily, radio signals are automatically received. Automatic reception is performed every hour from 2 AM to 4 AM. Automatic reception ends upon completion of satisfactory reception.

- ※ Automatic reception functions in the home time mode or world time mode. Please keep in mind that it does not function in other modes than the above.
- ※ Automatic reception is started one min after system reset.


- **Manual reception:** Radio signals can be compulsorily received by hand.
- ※ Manual reception functions in the home time mode. It does not function in other modes than the above.

Reception can be satisfactorily performed depending on the reception environment. According to the environment, radio signals may not be properly received. Check the [Reception result] to confirm that reception has been satisfactorily performed.

Official standard frequency of Japan (JJY)

Official standard frequency of Japan (JJY)

This watch can receive official standard frequencies from transmitting stations in Japan. The radio signal reception function is activated when the city code of the home time is set to TYO (Tokyo), SEL (Seoul), or HKG (Hong Kong).



【Official standard frequency of Japan: JJY】

JJY is operated by the National Institute of Information and Communications Technology (NICT).

JJY is transmitted from two stations in Japan. Each station transmits JJY in a different frequency.

- Fukushima
(Ohtakadoya-yama transmitting station: 40 KHz)
- Kyushu
(Hagane-yama transmitting station: 60 KHz)

The reception range from each transmitting station is approximately 1,000 km (1,000 km radius of each station).



Notice


About receiving radio signals

- The watch may display the incorrect time if it fails to receive radio signals properly because of interference. The watch may fail to receive radio signals depending on the location or reception conditions. In such a case, change the location of the watch.
- Radio signals can easily be received during nighttime hours due to its characteristics.
- The watch moves depending on the quartz movement (loss/gain: ± 30 seconds per month) when it is unable to receive radio signals.
- The time signal transmission may be stopped during maintenance of the facilities of each transmitting station or because of a lightning strike. In such a case, see each station's website for further information or contact SEIKO CUSTOMER SERVICE CENTER.
- Websites of transmitting stations (as of August 2006)
Japan: NICT (Japan Standard Time Group) <http://www.nict.go.jp>
- SEIKO CUSTOMER SERVICE CENTER: 0120-612-911 (toll free in Japan)

- ※ Whether the watch succeeds in receiving radio signals or not depends on the receiving conditions.
- ※ The watch cannot receive radio signals outside a reception range.

Appropriate Place to Keep a Radio-Controlled Watch

■ To enable the watch to receive radio signals easily




Place the watch where it can easily receive radio signals, for example, close to a window.

To enhance the reception of radio signals, do not move the watch by changing the orientation of the watch, tilting the watch, etc., while it is receiving radio signals.


This watch is equipped with the built-in antenna for receiving radio signals. The antenna is at the 12 o'clock position.

■ Conditions in which the watch may be unable to receive radio signals




- Close to home electrical appliances such as TV's, refrigerators, and air conditioners
- Close to OA devices such as PC's, fax machines, and mobile phones
- Close to furniture made of steel, such as a steel desk

Avoid these places when conducting a radio signal reception.



- Inside a building, between tall buildings, underground



- Close to overhead power lines, TV stations, and train cables




- In places generating radio interference, such as construction sites and in heavy traffic



- Inside a vehicle, train, airplane, etc.

Adjust the Time by Receiving Radio Signals (How to Carry Out Manual Reception)

① Place a watch



Remove the watch from your wrist and place it in a location that can easily receive radio signals, for example, close to a window.

② Press button **C** for two sec or more.



Pressing button **C** displays [RECEIVE] as shown above.


Press button **C** for two sec or more with the home time mode time display.

※ Reception cannot be performed in other modes than the home time mode.

③ Wait for a while with your watch is placed down.

It will take 13 min at maximum for reception.

Radio signal strength is displayed in four stages. (Updated every second)



Radio signal level display



Streaming animation indicating reception is displayed.


Please wait until the reception is completed without moving your watch.

Without wearing your watch, wait while placing your watch down and allowing it to remain still.

※ Pressing any button during reception cancels the reception.

④ Confirm the reception result

Could be
received



After 10 sec
or
press once

Reset to the home time mode



Could not
be received



After 10 sec
or
press once



Nothing
is
displayed.

The display indicates that reception is completed. The display continues for 10 sec. After 10 sec or by pressing button **C** once, it is reset to the home time mode.

- ※ Reception can be successfully performed depending on the weather and reception environment.
- ※ Reception cannot be performed outside the radio signal reception range.

If reception cannot be properly performed, change the location or direction of the watch. Also, the reception environment varies even in the same location depending on the time zone. Radio signals can easily be received during nighttime hours due to its characteristics.

If this message is displayed

CHECK!

The watch has been set to a mode for which reception cannot be performed. Refer to the following page for resetting.

When reception is not operated (If CHECK! is displayed)

If this message is displayed

CHECK!

Three conditions on the right side can be considered. Reset according to the flowchart on the right side.

The display is reset to the home time mode after 10 sec or by pressing button **C** once.

①





STP.W flashes: The stopwatch is operating.
Stop the stopwatch.
→ How to use the stopwatch. P.66

②



TMR flashes: The timer is operating.
Stop the timer.
→ How to use the timer. P.67

③



The city setting of the home time is incorrect.
Set the home time to TYO (Tokyo), SEL (Seoul), or HKG (Hong Kong).
→ Various Settings P.47

These three conditions may overlap

※ This watch receives The official standard frequency of Japan.

Confirm Reception Result

■ Confirm reception result

The latest reception result (success/failure) can be confirmed. This is displayed in either mode.

Reception
can be
performed.




Reception
cannot be
performed.



Nothing
is
displayed.

■ Confirm the date and time for which the latest reception was successfully performed.

① Press button **C** once.



Pressing button **C**
displays [RECEIVE]
as shown above.

Press button **C** under the condition
of home time mode.

② Displays the date and time for which reception was successfully performed.



Example: Reception was successful
at 3:10 AM on December 8.

The display is reset to the home time mode when one
min has elapsed or by pressing button **C** once.

※ In the home time mode, reception result is reset with no
display when the mode is changed to the various settings mode.

※ Continuously press button **C** for two sec or more to enter the receiving operation.
Press any button to cancel receiving operation.

World Main Area Time Zone List

	Names of the cities	C o u n t r y	Time difference with UTC
U T C	-----	Universal Coordinated Time	-----
L O N	London★	United Kingdom	+ 0 hour
P A R	Paris★	France	+ 1 hour
B E R	Berlin★	Germany	+ 1 hour
A T H	Athens★	Greece	+ 2 hour
C A I	Cairo★	Egypt	+ 2 hour
M O W	Moscow★	Russia	+ 3 hour
B G W	Baghdad	Iraq	+ 3 hour
T H R	Tehran★	Iran	+ 3.5 hour
D X B	Dubai	United Arab Emirates	+ 4 hour
K B L	Kabul	Afghanistan	+ 4.5 hour
K H I	Karachi	Pakistan	+ 5 hour
D E L	Delhi	India	+ 5.5 hour
D A C	Dacca	Bangladesh	+ 6 hour
R G N	Yangon	Myanmar	+ 6.5 hour
B K K	Bangkok	Thailand	+ 7 hour

	Names of the cities	C o u n t r y	Time difference with UTC
H K G	Hong Kong	China	+ 8 hour
S E L	Seoul	South Korea	+ 9 hour
T Y O	Tokyo	Japan	+ 9 hour
A D L	Adelaide★	Australia	+ 9.5 hour
S Y D	Sydney★	Australia	+ 10 hour
N O U	Nouméa	New Caledonia	+ 11 hour
W L G	Wellington★	New Zealand	+ 12 hour
H N L	Honolulu	U.S.A.	- 10 hour
A N C	Anchorage★	U.S.A.	- 9 hour
L A X	Los Angeles★	U.S.A.	- 8 hour
D E N	Denver★	U.S.A.	- 7 hour
C H I	Chicago	U.S.A.	- 6 hour
N Y C	New York★	U.S.A.	- 5 hour
C C S	Caracas	Venezuela	- 4 hour
R I O	Rio de janeiro★	Brazil	- 3 hour
P D L	Azores★	Azores Islands	- 1 hour

Cities marked with "★" use daylight saving time (as of August 2006).

※ The time differences and use of daylight saving time in each city are subject to change according to the governments of the respective countries or regions.

How to Use World Time

WRT Find out the time all over the world.

You can find out the time for 32 cities and regions all over the world.

- ① Set to the world time mode according to the "Mode change" on P.46.


※ The time of the city displayed last time is displayed when the mode is changed to the world time mode.

■ Universal Coordinated Time (UTC:Coordinated Universal Time)

UTC is the universal standard time coordinated through international agreement. It is used as the official time around the world.

■ Summer time (DST:Daylight Saving Time)

Summer time is daylight saving time. Advancing the watch one hour to prolong daytime during longer daylight hours in summer. Daylight saving time has been adopted in about 80 countries, mainly in Europe and North America. The adoption and duration of daylight saving time vary depending on the country.



How to Use the Single-Time Alarm

1-ALM Using the single-time alarm

An alarm that sounds only one time at the set time can be set.

- ① Set the single-time alarm mode according to "Mode change" on P.46.

- ② Set the alarm time.


B Plus
(Advance)

Press once: Forward 1 min
Long press: Forward 15 min

C Minus
(Return)

Simultaneously press buttons **B**
and **C** to cancel the setting.

※ When the time reaches the alarm time while setting,
the setting is reset and 「--:--」 is displayed.



- ③ When the alarm is set,

The single-time mark mode is displayed
in either mode after setting.



When the time reaches the set time, the alarm
sounds for 10 sec and the display is reset
to 「--:--」.

Press any button to stop the alarm sound.

- ※ Radio signal reception cannot be made in this mode.
- ※ The reception is suspended, when the alarm sounds during
radio signal reception.

How to Use the Daily Alarm

ALM Using the daily alarm

An alarm that sounds everyday at the set time can be set.

- ① Change the mode to the daily alarm mode according to "Mode change" on P.46.

※ When the mode is changed to the daily alarm mode, the last alarm set time is displayed.

- ② Set the alarm time.

A Long press
Enter the setting mode.

B or **C**
Time setting
(Time flashes)

A
Switching
(Hour to Min)

B or **C**
Min setting
(Min flashes)

A
Setting mode ended


Operation of buttons **B** and **C**.

One press : Forward one point
Long press : Fast forward
Stopped when released.



- ③ Alarm ON/OFF

Pressing button **B** or **C** switches ON/OFF.



When turning on, the daily alarm mark is displayed in either mode.

※ Pressing button **C** for an extended time, the alarm sound can be previewed.
(For 10 sec)

Press any button to stop alarm sound.

※ Radio signal reception cannot be performed in this mode.

※ Reception is suspended when the alarm sounds during radio signal reception.


How to Use the Stopwatch

STP. 11 Using the stopwatch

Time is measured in 1/100 sec unit.

The maximum measurement time is 9 hours 59 min 59.99 sec.

- ① Change the mode to the stopwatch mode according to "Mode Change" on P.46.



※ Radio signal reception cannot be performed in this mode.

※ Radio signal reception cannot be performed during stopwatch operation.

② -1: Normal measurement

B

Start

B

Stop

C

Reset

※ When using the stopwatch for one hour or more in a dark place, it is recommended to turn off (stop) the P.SAVE.

P.SAVE ON/OFF → P.53

② -2: Split time (intermediate time) measurement

B

Start

C

Split

B

Stop

C

Reset

The split time is displayed for 5 sec.

Example: Measurement when passing intermediate points

Measurement of respective points of [Start, A point, B point, Goal]

B

Start

C

A Point Passed

(Passing time is displayed)

C

B Point Passed

(Passing time is displayed)

B

Goal

(Stop)

C

Reset

How to Use the Timer

TMR Using the timer

The timer can be set from 1 min to 9 hours 59 min by the minute.

- ① According to the "Mode change" on P.46, change the mode to the timer mode.

※ When the mode is changed to the timer mode, the latest set time is displayed.

- ② Set the time.

A Long press
Changed to the set mode.

B or **C**
Timer set
(Hour flashes.)


A
Change
(Hour to Min)

B or **C**
Min setting
(Min flashes.)

A
Setting mode ended

Operation of buttons **B** and **C**.

One press : Forward one point
Long press : Fast forward
Stopped when released.



- ③ Operate the timer.

The alarm sounds every sec from 3 seconds before stop.
The alarm continuously sounds for 5 sec after the counter reaches 0.

The timer is stopped when the counter reaches 0 and returns to the set time.

Press any button to stop the alarm.

- ※ Press the reset (button **C**) to reset to the set time.
- ※ For using the timer for 1 hour or more in a dark place, it is recommended to turn off (stop) the P.SAVE.
ON/OFF of the P.SAVE → P.53

※ Radio signal reception cannot be made in this mode.

※ Radio signal reception cannot be made during timer operation.

About Message Display

■ About message display

This watch displays a message unique to each specification.

Only preset messages are displayed.

Original messages cannot be prepared.

- ① In the home time mode, long press button **B**.



- ② A message is displayed.



Ex.: In the case of a message of [WIRED]

The message is stopped after scrolling.

Press button **B** to return to the home time mode.

Specification

■ Specification

※ The specifications are subject to change without prior notice due to product improvements.

1. Frequency of crystal oscillator ··· 32,768 Hz (Hz = Hertz ... Cycles per second)
2. Loss/gain (monthly rate) ········· Less than 30 seconds (Except during automatic time setting, worn on the wrist within normal temperature range between 5°C and 35°C.)
3. Operational temperature ········· Between -5°C and +50°C (Display function works between 0°C and +50°C)
4. Display medium ··················· Nematic Liquid Crystal, FEM (Field Effect Mode)
5. Power source ····················· Secondary battery, 1 piece
6. Duration of operation ··············· Approximately 3 months (after being fully charged, exposed to no light, built-in illuminating light used once a day for 2 seconds, alarm sounded once a day for 10 seconds, radio signal reception once a day for 10 minutes, power save activated for 6 hours per day)
7. Time setting by receiving the JJY-LF radio signal ········· Automatic reception : 2:00 AM (If the watch fails to receive radio signals, it will attempt to receive signals again at 4:00 a.m.)
※After having received the JJY-LF radio signal, the watch moves depending on the quartz movement until the next reception. Manual reception is also possible.
8. Illuminating light ··················· Electroluminescent panel
- 9.IC(Integrated circuit) ··············· Oscillator, frequency divider and driving circuit C-MOS-IC, 3 pieces

■ Others

■ BUILT-IN ILLUMINATING LIGHT

The brightness of the electroluminescence (EL) panel used for the built-in illuminating light will decrease when the battery voltage becomes low. The brightness of the electroluminescence (EL) panel will also gradually decrease with the passage of time.

**The brightness of the electroluminescence (EL) panel will decrease by one-half after a total of approximately 120 hours of lighting. When the brightness of the electroluminescence (EL) panel becomes too dark, first charge the watch sufficiently. If still too dark after charging the watch, replace the electroluminescence (EL) panel. Consult the retailer from whom the watch was purchased concerning panel replacement. A fee will be charged for replacement.*

■ The Electroluminescent Panel


After 5 years of use, the contrast of the electroluminescence (EL) panel may decrease and digits may not be easy to read.

Consult the retailer from whom the watch was purchased concerning panel replacement. A fee will be charged for replacement.

When the Following Messages are Displayed

Refer to each guide when either of the following messages is displayed.

P.SAVE



The P.SAVE is working.

→ P.52

SLEEP



The P.SAVE is working.

→ P.52

CHECK!



The watch has been set to a mode for which reception cannot be performed.

→ P.60


CHARGE



The remaining battery amount is insufficient.

→ P.51

Nothing is displayed.



The remaining battery amount is insufficient.

→ P.51

All messages are lit.



Buttons **B** and **C** are simultaneously pressed at each mode of the home time mode.

→ Press any button to reset to the home time mode.

TOUBLESHOOTING

Trouble		Possible Cause	Solution
Radio signals reception	The watch cannot receive radio signals.	The watch is moved while it is receiving radio signals.	Do not move the watch or do not change the orientation of the watch while it is receiving radio signals. For details, refer to "To enable the watch to receive radio signals easily" on P. 57.
		The reception is cancelled while the watch is receiving radio signals.	Repressing button A during reception cancels the reception while the automatic or manual reception is being performed.
		During automatic reception, the watch was left where radio signals were weak or where it could not receive radio signals.	Place the watch where it can easily receive radio signals. Refer to "To enable the watch to receive radio signals easily" on P. 57
		JJY-LF stations may stop transmitting time signals for some reasons.	See the website of Communication Research Laboratory (CRL) for further information concerning the transmission of time signals. Check the URL of the CRL website on P. 56. For details, refer to "Radio Signal Reception" on P. 55
		The stopwatch or timer is operating.	Stop the stopwatch or timer (or both). For details, please refer to the "When Reception is Not Working" on P.60.
		Any city code for which the reception does not work is selected to the home time.	When using your watch by receiving radio signals, set the city code of the home time to TYO (Tokyo), SEL (Seoul), or HKG (Hong Kong). For details, please refer to the "When Reception is Not Working" on P.60.

TOUBLESHOOTING

Trouble		Possible Cause	Solution
Display of incorrect time or misalignment of the hands	The watch temporarily gains or loses time.	The watch receives a wrong radio signal because of a result of influence of various external	Place the watch where it can receive radio signals more easily. Conduct the manual reception if necessary. For details, refer to "Conditions in which the watch may be unable to receive radio signals" on P. 57 or "Adjust the Time by Receiving Radio Signals (How to Carry Out Manual Reception)" on P. 58.
		The watch has been left in extremely high or low temperatures for a long time.	When the watch returns to normal temperature, the condition will be corrected. Conduct the manual reception if necessary. For details, refer to "Adjust the Time by Receiving Radio Signals (How to Carry Out Manual Reception)" on P. 58. If the watch hands are not set to current time even after conducting the manual reception, consult the retailer from whom the watch was purchased.
	The watch has a time-lag on an hourly basis.	The city setting of the home time that has been set to a city or region that differs from what you intended.	Check the city code setting of the home time to reset.Set the city code to TYO (Tokyo) to display Japanese time.For details, please refer to the "Various Settings" on P.47.
		The summer time (DST) has been set to the home time.	When DST is displayed at the left lower portion of the home time display, the summer time has been set. If the summer time setting is not required, turn off the summer time setting.For details, please refer to the "Various Settings" on P.47.

Trouble		Possible Cause	Solution
Charging the watch	The stopped watch was exposed to adequate light for a longer time than "the time required for fully charging the watch," however, it does not resume its normal one-second interval movements.	The light is too weak or the manner of lighting the watch has been altered while the watch is being charged.	Place the watch where it can be exposed to an adequate light source. Make sure that the manner of lighting the watch is not altered while the watch is being charged.
		The built-in IC has fallen into an unstable condition.	Reset the built-in IC. For details, refer to "How to Reset the Built-in IC" on P. 74.
Button operation	Buttons or crown cannot be operated.	The energy stored in the watch runs low.	Refer to "Display and Remaining Battery Amount" on P. 50 to charge the watch.
Display	Nothing is displayed.		
Others	Blur on the dial glass persists.	Small amount of water has got inside the watch due to deterioration of the gasket, etc.	Contact the retailer from whom the watch was purchased.

※For the solutions of troubles other than the above, contact the retailer from whom the watch was purchased or the SEIKO CUSTOMER SERVICE CENTER.

Abnormal Display or Improper Function


■ How to Reset the Built-in IC

When the watch shows an abnormal display or does not properly function, reset the built-in IC. Then the watch will resume its normal operation.

- ① Press buttons **A**, **B**, and **C** simultaneously for an extended time, and release them when the display is extinguished.



It is reset



When the display is reset from a state where nothing is displayed, the time of the home time mode is displayed.

The time and calendar start counting from 12:00:00 AM, Sunday, January 1st, 2006.

Automatic reception is started after one min.

- ② If no radio signals could be received, adjust the time by manual reception or by hand.


■ Manual reception → P.58

■ Various Settings (Time adjustment) → P.47

※ After recovery, Japan Standard Time (City code: TYO) is displayed at the home time and local time.


TO PRESERVE THE QUALITY OF YOUR WATCH

■ PLACES TO KEEP YOUR WATCH



- If the watch is left in a temperature below -5°C or above $+50^{\circ}\text{C}$ for a long time it may function improperly or stop operating.

※ This watch is so adjusted that it will maintain stable time accuracy in normal temperatures. ($5^{\circ}\text{C} \sim 35^{\circ}\text{C}$) It will lose or gain slightly, but it will regain high time accuracy when it returns to normal temperature.



- Do not leave the watch in a place where it is subjected to strong magnetism or static electricity.



- Do not leave the watch where there is strong vibration.
- Do not leave the watch in a dusty place.



- Do not expose the watch to gases or chemicals. (Ex.: Organic solvents such as benzene and thinner, gasoline, nail polish, cosmetic spray, detergent, adhesives, mercury, and iodine antiseptic solution.)
- Do not leave the watch in a hot spring, or do not keep it in a drawer having insecticides inside.

TO PRESERVE THE QUALITY OF YOUR WATCH

⚠ CAUTION

■ CARE OF YOUR WATCH

The case and bracelet touch the skin directly just as underwear. If they are left dirty, the edge of a sleeve may be stained with rust of those who have a delicate skin may have a rash.


After removing the watch from your wrist, wipe perspiration or moisture with a soft cloth. This will prevent the watch from being soiled, adding to the life of the gasket.

METAL BRACELET

Clean the watch bracelet with a soft toothbrush dipped in water or soapy water. If your watch is not water-resistant, be careful not to get the case wet when cleaning.

LEATHER BAND

When removing moisture from a leather band, do not rub the band with the cloth as this may discolor it or reduce its gloss. Be sure to blot up the moisture using a soft dry cloth.



SOFT PLASTIC BRACELET

If your watch has a soft plastic band such as urethane band, do not leave the watch under a fluorescent lamp or direct sunlight for a long time, or do not leave the band soiled. Otherwise, the band may be discolored, hardened or broken. Also, do not keep the watch in a place where it is exposed to high humidity, or do not leave the band wet with perspiration or water. Otherwise, the band may be discolored in a very short time.

When the band is soiled, rinse it in soapy water. Do not use solvents for cleaning as some solvents may deteriorate the band.

If your watch has a semitransparent urethane band which is easily discolored, special care should be taken to keep it clean. Depending on the condition of use, the semitransparent band may be discolored after several months of use.

- If your watch is not water-resistant, be careful not to get wet with water or sweat. When it gets wet with water or sweat, wipe it thoroughly dry with a hygroscopic cloth.
- If your watch is 5, 10 or 20 bar water resistant, rinse it in a bowl of fresh water after used in seawater. Do not use chemicals to wash it.
- If your watch has a rotating bezel, clean the bezel regularly. Otherwise, dust will gather under it, making the rotation harder.

⚠ CAUTION**■ RASH AND ALLERGY**

- Adjust the bracelet or band so that there will be a little clearance between the bracelet or band and your wrist to avoid accumulation of perspiration.
- If you are constitutionally predisposed to rash, the band may cause you to develop a rash or an itch depending on your physical condition.
- The possible causes of the rash are as follows:
 1. Allergy to metals or leathers
 2. Rust, dust or perspiration on the watch or band
- If you develop any skin reactions, take off the watch and consult a doctor immediately.

⚠ CAUTION

If your watch is of the fob or pendant type, the strap or chain attached to the watch may damage your clothes, or injure the hand, neck, or other parts of your body.

⚠ WARNING

- If your watch is 3 bar water resistant, do not use it in water.
- If your watch is 5 bar water resistant, do not use it in any type of diving including skin diving.
- If your watch is 10 or 20 bar water resistant, do not use it in saturation diving or scuba diving.

■ About bathing

- Your watch can be worn while bathing if it is equipped with water resistance over 10 bar. In that case, please note the following carefully.
- Please do not operate your watch (Crown operation, Button operation etc.) when it is wet with soap or shampoo. It sometimes causes a reduction in the water proofing.
- When the watch gets warm due to warm water, the watch could gain or lose time to some degree. However, the watch will return to its usual accuracy at normal temperatures.

TO PRESERVE THE QUALITY OF YOUR WATCH

⚠ CAUTION

■ WATER RESISTANCE

- Check the dial or case back of your watch for the water resistant quality, and then see the table below.
- Do not turn or pull out the crown when the watch is wet, as water may get inside the watch.

						
		Designed and manufactured to withstand the water usually experienced in a daily living such as splashes and rain.	Designed and manufactured for swimming and kitchen work.	Skindiving without scuba and bathing.	Genuine diving using scuba or helium gas.	Crown operation when the watch is wet.
"WATER RESISTANT" is not inscribed on the back of your watch case.		×	×	×	×	×
"WATER RESISTANT" is inscribed on the back of your watch case.		○	×	×	×	×
"WATER RESISTANT 5·10·15·20 BAR.", "WATER RESISTANT" and  marks inscribed on the back of your watch case.	5 BAR.	○	○	×	×	○
	10·15·20 BAR.	○	○	○	×	○


■ PRECAUTIONS ON WEARING YOUR WATCH

Take utmost care in the following cases:

- When clasping and unclasping the band, you may damage your nail, depending on the type of clasp used with the band.
- In case you tumble and fall or bump into others with the watch worn on your wrist, you may be injured by the reason of the fact that you wear the watch.
- When you make contact with children, especially with infants, they may get injured or

■ PERIODIC CHECK

- We suggest that you have your watch checked by every 2 or 3 years or when the battery is replaced for oil condition, battery electrolyte leakage or damage due to water or sweat. After checking the watch, adjustment and repair may be required.
- When the replacing the parts or battery, please specify “SEIKO GENUINE PARTS” . If an old battery is kept in the watch for a long time, electrolyte leakage from the battery may damage the module.
- Be sure to have the gasket and push-pin replaced with new ones by when checking the watch or the battery is replaced.



■ NOTES ON THE REPLACEMENT PARTS

1. If the watch requires service, take it to the retailer from whom the watch was purchased. If the trouble occurs within the guarantee period, submit the certificate of guarantee together with the watch. Guarantee coverage is spelled out in the certificate of guarantee. Please read it carefully and keep the certificate for ready.
2. SEIKO makes it a policy to usually keep a stock of spare parts for its watches for 7 years. In principle, your watch can be reconditioned within this period if used normally. (Replacement parts are those which are essential to maintaining the functional integrity of the watch.)
3. The number of years that a watch is considered repairable may vary greatly depending on the condition under which it was used, and normal accuracy may not be achieved in some cases. We recommend, therefore, that you consult the retailer from whom the watch was purchased, when having them repair your watch.
4. The case, dial, hands, glass, bracelet, or parts thereof may be replaced with substitutes if the originals are not available.

WIRED
デジタル

取扱説明書
INSTRUCTION

説明書 W360C

WIRED 説明書 W36系

セイコー製品について、修理その他のご相談は「お買いあげ店」でうけたまわっております。
なお、ご不明の点は下記へお問い合わせください。

● お客様相談室

〒101-0044 東京都千代田区鍛冶町2-1-10 (03)3535-2211

〒550-0013 大阪市西区新町1-4-24 (06)6538-6541
大阪四ツ橋新町ビルディング8階

お客様相談窓口 全国共通フリーダイヤル **0120-612-911** (上記の最寄地に着信します)

セイコーウオッチ株式会社

本 社 東京都港区芝浦1丁目2番1号 〒105-8467